

# Acoustical Wallcovering Adhesives

## 1. General:

- Recommendations of wallcovering adhesive manufacturer should be strictly followed and take precedence.
- Apply premixed, undiluted, heavy-duty wallcovering adhesive to the wall—NOT THE FABRIC.
- Allow adhesive to become tacky, not dry.
- A clear, non-staining adhesive will help prevent problems if dropped on the face of the material.
- If adhesive lands on the face of the material, check with adhesive manufacturer.

## 2. Recommendations:

- Shur-stik 111                      Gibson-Homans, Twinsburg,OH
- Pro 838                              Roman Adhesives, Calumet,IL

The above recommended adhesives are appropriate based upon practical field experience and in no way, expressed or implied, are meant to be a warranty. Contact the adhesive supplier or manufacturer for final recommendations for type and application methods.

For best results, it is recommended that a qualified textile wallcovering installer be employed.